CALEXOTICS®

SE-0077-30-3

SILICONE REMOTE RECHARGEABLE EGG™



FEATURES:

- Remote control and rechargeable - use alone or with a partner!
- 12 intense functions of vibration, pulsation and escalation
- Waterproof stimulator may be used independently of remote
- Easy retrieval cord
- Instructions included
- Easy push-button control
- Extended 32.75'/10 m range
- EC-R+TTE certificate included
- USB rechargeable (stimulator and remote) – dual charging cord included
- Complete charge in 1 hour
- Runs for 40 minutes on high speed and 70 minutes on low speed

12 SILICONE WATER PROOF EXTENDED RANGE USB RECHARGEABLE

MATERIALS: Silicone (stimulator) ABS with PU Cote (controller, décor) ABS with Silver Plating (button)

MEASUREMENTS:

2.75" x 1.25"/7 cm x 3.25 cm

CHARGING INFORMATION:

The bullet must be activated to pair with the remote. A flashing LED light will indicate the bullet is activated. Ensure the bullet is deactivated after each use to preserve battery life. Bullet will automatically deactivate after 30 minutes of inactivity. Product has a memory chip feature and will resume on the last function used. LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 60 minutes; Run time on high: 40 minutes; Run time on low: 70 minutes.

OPERATING INSTRUCTIONS:

To use bullet independently:

1. Press and hold the power button on the bullet for 3 seconds to activate; a flashing LED light will indicate the bullet is activated.
2. Press the function button to turn on vibrations.
3. Press the function button repeatedly until the desired function is reached.
4. To turn off vibrations and deactivate bullet, press and hold the power button for 3 seconds. The flashing LED will turn off.

To use with remote:

1. Press and hold the power button on the bullet for 3 seconds to activate; a flashing LED light will indicate the bullet is activated.
2. Using the remote, press the XO button once to turn on vibrations.
3. Press the XO button on the remote repeatedly until the desired function is reached.
4. To turn off vibrations, press and hold the XO button on the remote for 3 seconds.
5. To deactivate, press and hold button on the bullet for 3 seconds.