CALEXOTICS®

LOCK-N-PLAY™ REMOTE PULSATING PANTY TEASER



FEATURES:

- Remote control and rechargeable – use alone or with a partner!
- Perfect placement every time with magnetic tab wings that attach securely on panty
- Perfectly contoured petite, slim design with pinpoint thumping action
- 12 functions of thumping pulsation with synchronous vibration
- State-of-the-art memory chip resumes on last function used
- Waterproof stimulator may be used independently of remote
- Easy push-button control
- Extended 32.75'/10 m range
- RED certificate included
- USB rechargeable (stimulator and remote) – dual charging cord included
- Complete charge in 1 hour
- Runs for 30 minutes on high speed and 35 minutes on low speed

12 | SILICONE | WATER PROOF | PANTY LOCK TECHNOLOGY | EXTENDED RANGE | REMOTE CONTROL | USB RECHARGEABLE

MATERIALS: Silicone (stimulator) ABS with PU Cote (controller) ABS with Silver Plating (button, magnetic backing)

MEASUREMENTS:

3.75" x 1"/9.5 cm x 2.5 cm

CHARGING INFORMATION:

The stimulator must be activated to pair with the remote. A flashing LED light will indicate the stimulator is activated. Ensure the stimulator is deactivated after each use to preserve battery life. Stimulator will automatically deactivate after 30 minutes of inactivity. Product has a memory chip feature and will resume on the last function used. LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 1 hour; Run time on high: 30 minutes; Run time on low: 35 minutes.

OPERATING INSTRUCTIONS:

To use stimulator independently:

1. Press and hold the button on the stimulator for 3 seconds to activate; a flashing LED light will indicate the stimulator is activated.
2. Press the button to turn on vibrations.
3. Press the button repeatedly until the desired function is reached.
4. To turn off vibrations and deactivate stimulator, press and hold the button for 3 seconds. The flashing LED will turn off.

To use with remote:

1. Press and hold the button on the stimulator for 3 seconds to activate; a flashing LED light will indicate the stimulator is activated.
2. Using the remote, press the XO button once to turn on vibrations.
3. Press the XO button on the remote repeatedly until the desired function is reached.
4. To turn off vibrations, press and hold the XO button on the remote for 3 seconds.
5. To deactivate, press and hold button on the stimulator for 3 seconds.