CALEXOTICS®

SLAY® #THRUSTME



FEATURES:

- Remote control, rechargeable Silicone massager with passionate thrusting and sensual waves
- 10 powerful functions of synchronous vibration plus thrusting action
- Stimulator may be used independently of the remote
- State-of-the-art memory chip resumes on last function used
- Security travel lock feature – hold for 3 seconds to turn on or off
- Extended 32.75'/10 m range
- RED certificate included
- USB rechargeable (stimulator and remote) – dual charging cord included
- Complete charge in 1.5 hours
- Runs for 50 minutes on high speed and 80 minutes on low speed



MATERIALS: Silicone (massager, buttons) ABS with Metallic Plating (décor) ABS (remote)

MEASUREMENTS:

3.25" x 1.25"/8.25 cm x 3.25 cm (overall)

CHARGING INFORMATION:

The stimulator must be activated to pair with the remote. A glowing LED light will indicate the stimulator is activated. Ensure the stimulator is deactivated after each use to preserve battery life. Product has a memory chip feature and will resume on the last function used. LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 1.5 hours; Run time on high: 50 minutes; Run time on low: 80 minutes.

OPERATING INSTRUCTIONS:

To use stimulator independently:

1. Press and hold the button on the stimulator for 3 seconds to activate; a glowing LED light will indicate the stimulator is activated.
2. Press the button to turn on.
3. Press the button repeatedly until the desired function is reached.
4. To turn off and deactivate stimulator, press and hold the button for 3 seconds. The LED will turn off.

To use with remote:

1. Press and hold the power button on the remote for 3 seconds to activate stimulator; a glowing LED light will indicate the stimulator is activated.
2. Using the remote, press the function button once to turn on.
3. Press the function button on the remote repeatedly until the desired function is reached.
4. To turn off and deactivate stimulator, press and hold the power button on the remote for 3 seconds. The LED will turn off.