CALEXOTICS®

OPTIMUM POWER® MASTURBALL™



FEATURES:

- Totally self-contained rechargeable masturbator with dual motors
- Texturized pleasure chamber with teasing ticklers for added sensations
- 10 functions of intense vibration, pulsation and escalation
- 3 levels of rhythmic compression
- Easy-grip edges for a powerful hold
- Instructions included
- Easy LED push-button controls – hold for 3 seconds to turn on
- 2 removable magnetic caps for safe and clean storage
- 100% waterproof
- USB rechargeable – charging cord included
- Complete charge in 2.5 hours
- Runs for 55 minutes on high speed and 65 minutes on low speed

10+ | WATER PROOF | Dual Motors | USB RECHARGEABLE

MATERIALS: ABS (stroker) TPR (sleeve)

MEASUREMENTS:

4.5" x 2.25"/11.5 cm x 5.75 cm

CHARGING INFORMATION:

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 2.5 hours; Run time on high: 55 minutes; Run time on low: 65 minutes.

OPERATING INSTRUCTIONS:

1. To turn product on, press and hold the power button for 3 seconds. A glowing LED light will indicate the product is on.
2. To activate vibrating functions, press the vibrating button once. Continue pressing the button until desired function is reached.
3. To turn off vibrating functions at any time, press and hold the vibrating button for 2 seconds. To restart, simply press the button again.
4. To activate compression levels, press the compression button once. Continue pressing the button until the desired level is reached.
5. To turn off the compression levels at any time, press and hold the right button for 2 seconds. To restart, simply press the button again.
6. To turn product off, press the power button once.